


12F standard color coding (EIA/TIA) - pre-cabled Fiber connecting scheme

General LC

With 12 fibers per loose tube, 2 tubes will enter each tray. 1 Loose tube will be used for the top 12 LC connections and the other will be used for the bottom 12 LC connections.


FIBER COLOR	connector position
blue	1
orange	2
green	3
brown	4
grey	5
white	6
red	7
black	8
yellow	9
purple	10
pink	11
turquoise	12

blue	1
orange	2
green	3
brown	4
grey	5
white	6
red	7
black	8
yellow	9
purple	10
pink	11
turquoise	12




Pre-terminating LC - Right Hand patch

The picture below shows how pre-terminating is done when splicing happens on the left side of the tray. The thickest and thinnest lines inside the splicing module represent 900µm and 250µm respectively. The FOP tubes are placed into the FOP tube holder. The fibers are routed as shown in the picture.



Pre-terminating LC - Left Hand Patch


The picture below shows how pre-terminating is done when splicing happens on the right side of the tray. The thickest and thinnest lines inside the splicing module represent 900 μ m and 250 μ m respectively. The FOP tubes are placed into the FOP tube holder. The fibers are routed as shown in the picture.



General SC


With 12 fibers per loose tube, 1 tube will enter each tray.

FIBER COLOR	connector position
blue	1
orange	2
green	3
brown	4
grey	5
white	6
red	7
black	8
yellow	9
purple	10
pink	11
turquoise	12



Pre-terminating SC - Right Hand Patch

The picture below shows how pre-terminating is done when splicing happens on the left side of the tray. The thickest and thinnest lines inside the splicing module represent 900 μ m and 250 μ m respectively. The FOP tube is placed into the FOP tube holder. The fibers are routed as shown in the picture.



Pre-terminating SC - Left Hand Patch

The picture below shows how pre-terminating is done when splicing happens on the right side of the tray. The thickest and thinnest lines inside the splicing module represent 900 μ m and 250 μ m respectively. The FOP tube is placed into the FOP tube holder. The fibers are routed as shown in the picture.

